

DIGITAL MUSIC PLAYER MP3&WMA

USER MANUAL

Before operating this product, please first read this user manual carefully.

SPECIFICATIONS

- Storage capacity 128MB/256MB/512MB/1GB (according to model)
- Music format MP3, WMA
- Power supply single AAA Battery
- USB2.0 read 1033KB/S, write 955KB/S
- Supported operating system Windows 98/SE/ME/2000/XP/Mac OS X
- Earphone max output (L) 10mW + (R) 10mW (32ohm)

STANDARD ACCESSORIES

Please check that the following items are in the box:

- MP3 Player
- User Manual
- Earphones
- Driver CD (only required for Windows 98/SE)
- USB Cable
- AAA Battery

OPERATING INSTRUCTIONS

Hold:

The Hold switch is above the LED indicator light.
Slide it up to prevent accidental pressing of the buttons.
Slide it down and the buttons can be used normally.

Play:

Slide the Hold button down, then within approximately 5 seconds, press and hold the ▶ ■ button – the LED indicator will flash. Then press this button again to start playback.

Pause:

While the player is in play mode, press the ▶ ■ button to pause playback.
To resume playback, press the ▶ ■ button again. If playback is not resumed within approximately 30 seconds, the unit will switch off automatically in order to conserve battery power.

Previous/Next:

To skip to the previous or the next track, press the ◀◀ or the ▶▶ button respectively during play mode.

Vol+ / Vol-:

To increase or decrease the volume, press and hold the + or - button respectively during play mode.

Note:

If there is no operation within approximately 30 seconds when the unit is switched on, the unit will power off automatically to conserve battery power.

CONNECTING THE MP3 PLAYER TO THE PC

With the MP3 player switched off (either with or without battery installed), connect it to your PC with the USB cable provided. The PC will detect the unit automatically (except Windows 98/SE). The player will be detected as a “removable disk”. A constant blue LED will indicate this.

TRANSFERRING AND DELETING MUSIC FILES

You are advised to transfer files from your PC to the unit by using the copy-and-paste method to prevent lost files. A flashing LED indicates that the unit is in the process of uploading or downloading files onto the unit. During this process, please do not disconnect the unit from the PC as this may cause errors to occur in the programs, or files to be lost.

To delete files from the unit, this can be done via the usual method through the PC.

DISCONNECTING THE MP3 PLAYER FROM THE PC

You are advised to disconnect the player from the PC as follows:

- a)** Right click on the “Removable disk” icon in “My Computer”
- b)** Select “Eject” from the list.
- c)** Ensure that “removable disk” icon has been removed from the screen. You can now disconnect the MP3 Player from the PC.

Alternatively, you can also disconnect the unit by:

- a)** Look for a “Safely Remove Hardware” icon on the bottom right of the taskbar on your desktop screen. In Windows XP, a slanted arrow above a rectangular object usually represents it (please note that this icon varies with other Windows versions). If you are not sure which is the icon, move your cursor over the icon and wait for the description to appear.
- b)** Right click on the icon, then follow your computer’s instructions to remove the drive.
- c)** You can now remove the MP3 Player after the “Safe To Remove Hardware” bubble is displayed.

If unsure, you could always disconnect the MP3 Player after shutting down the PC.

TROUBLESHOOTING

The Player cannot be switched on:

Please make sure the battery is new and that it is installed correctly. Also, check that the Hold switch is in the off position.

No sound can be heard from the earphones:

Please make sure that the volume is not turned down, and the earphones are properly connected.

Make sure that the music is not copy-protected (i.e. downloaded from a commercial download site).

Music could not be downloaded onto the player properly:

Please check that the player is properly connected to the PC.

Check that the CD driver is properly installed (Windows 98/SE only).

Make sure that your OS is up-to-date (using Windows Update).

For online support, please visit www.SOSmp3.com